


Navigation and Ancillary Information Facility

Frames Kernel FK

March 2010




Introduction

Navigation and Ancillary Information Facility


What does the FRAMES subsystem do?


- It establishes relationships between reference frames used in geometry computations -- it "chains frames together."
 - We often call this set of relationships a frame tree
- It connects frames with the sources of their orientation specifications.
- Based on these relationships and orientation source information, it allows SPICE software to compute transformations between neighboring frames in the "chain," and to combine these transformations in the right order, thus providing an ability to compute orientation of any frame in the chain with respect to any other frame in the chain at any time. *

^{*} If the complete set of underlying SPICE data needed to compute the transformation is available.




Sample Frame Tree





Frame Classes

Frame class	<u>Examples</u>
Inertial	 Earth Equator/Equinox of Epoch (J2000,) Planet Equator/Equinox of Epoch (MARSIAU,) Ecliptic of Epoch (ECLIPJ2000,)
Body-fixed	 Solar system body IAU frames (IAU_SATURN,) High accuracy Earth frames (ITRF93,) High accuracy Moon frames (MOON_PA, MOON_ME)
CK-based	 Spacecraft (CASSINI_SC_BUS,) Moving parts of an instrument (MPL_RA_JOINT1,)
Fixed Offset	 Instrument mounting alignment (CASSINI_ISS_NAC,) Topocentric (DSS-14_TOPO,)
Dynamic nes Kernel	GeomagneticGeocentric Solar EquatorialPlanet true equator and equinox of date



Frames Class Specifications

Navigation and Ancillary Information Facility

Frame class Frame Defined in	Orientation data provided in
------------------------------	------------------------------

Inertial Toolkit Toolkit

Bodyfixed Toolkit or FK PCK

CK based FK CK

Fixed offset FK FK

Dynamic FK Toolkit, or computed

using FK, SPK, CK, and/or

PCK

FRAMES Subsystem Interfaces

Navigation and Ancillary Information Facility

SXFORM/PXFORM

returns state or position transformation matrix


```
CALL SXFORM ( 'FROM_FRAME_NAME', 'TO_FRAME_NAME', ET, MAT6x6 )
CALL PXFORM ( 'FROM_FRAME_NAME', 'TO_FRAME_NAME', ET, MAT3X3 )
```

SPKEZR/SPKPOS

returns state or position vector in specified frame


```
CALL SPKEZR ( BOD, ET, 'FRAME_NAME', CORR, OBS, STATE, LT )
CALL SPKPOS ( BOD, ET, 'FRAME NAME', CORR, OBS, POSITN, LT )
```

The above are FORTRAN examples, using SPICELIB modules. The same interfaces exist for C, using CSPICE modules, and for Icy and Mice.



What are the Names of Frames?

- Refer to "NAIF IDs" Tutorial for an introduction to reference frame names and IDs
- Refer to FRAMES.REQ for the list of NAIF "built in" (hard coded) inertial and body-fixed frames
- Refer to a project's Frames Kernel (FK) file for a list of frames defined for the spacecraft, its subsystems and instruments
- Refer to an earth stations FK for a list of frames defined for the DSN and other stations
- Refer to the moon FKs for descriptions of the body-fixed frames defined for the moon



Frames Kernel File

Navigation and Ancillary Information Facility

- Uses the SPICE text kernel file standards
- Loaded using the FURNSH routine
- Usually contains comprehensive information about the defined frames in the text section(s) of the file
- Contains frame definition information consisting of a set of keywords in the data sections of the file. Below are examples of a CK-based frame and a fixed-offset frame definitions:


CK-based Frame Example

```
FRAME_DAWN_SPACECRAFT = -203000
FRAME_-203000_NAME = 'DAWN_SPACECRAFT'
FRAME_-203000_CLASS = 3
FRAME_-203000_CLASS_ID = -203000
FRAME_-203000_CENTER = -203
CK_-203000_SCLK = -203
CK_-203000_SPK = -203
```

Fixed-offset Frame Example

```
FRAME DAWN FC1
                       = -203110
FRAME -203110 NAME
                       = 'DAWN FC1'
FRAME -203110 CLASS
FRAME -203110 CLASS ID
                       = -203110
FRAME -203110 CENTER
                       = -203
TKFRAME -203110 RELATIVE =
                         'DAWN SPACECRAFT'
TKFRAME -203110 SPEC
                       = 'ANGLES'
TKFRAME -203110 UNITS
                       = 'DEGREES'
TKFRAME -203110 ANGLES
                       = (0.0, 0.0, 0.0)
                       = (1, 2, 3)
TKFRAME -203110 AXES
```

These examples are discussed in detail on the next few slides



Navigation and Ancillary Information Facility

```
FRAME_DAWN_SPACECRAFT = -203000

FRAME_-203000_NAME = 'DAWN_SPACECRAFT'

FRAME_-203000_CLASS = 3

FRAME_-203000_CLASS_ID = -203000


FRAME_-203000_CENTER = -203

CK_-203000_SCLK = -203

CK_-203000_SPK = -203
```

```
FRAME DAWN FC1
                       = -203110
FRAME -203110 NAME
                       = 'DAWN FC1'
FRAME -203110 CLASS
FRAME -203110 CLASS ID
                       = -203110
FRAME -203110 CENTER
                       = -203
TKFRAME -203110 RELATIVE = 'DAWN SPACECRAFT'
TKFRAME -203110 SPEC
                       = 'ANGLES'
TKFRAME -203110 UNITS = 'DEGREES'
                       = ( 0.0, 0.0, 0.0 )
TKFRAME -203110 ANGLES
TKFRAME -203110 AXES
                       = (1, 2, 3)
```

 The Frame ID is an integer number used by the SPICE system as a "handle" in buffering and retrieving various parameters associated with a frame. In an FK it "glues" together the keywords defining the frame.



Navigation and Ancillary Information Facility

```
FRAME_DAWN_SPACECRAFT = -203000

FRAME_-203000_NAME = 'DAWN_SPACECRAFT'

FRAME_-203000_CLASS = 3

FRAME_-203000_CLASS_ID = -203000


FRAME_-203000_CENTER = -203

CK_-203000_SCLK = -203

CK_-203000_SPK = -203
```

```
FRAME DAWN FC1
                       = -203110
FRAME -203110 NAME
                       = 'DAWN FC1'
FRAME -203110 CLASS
FRAME -203110 CLASS ID
                       = -203110
FRAME -203110 CENTER
                       = -203
TKFRAME -203110 RELATIVE = 'DAWN SPACECRAFT'
TKFRAME -203110 SPEC
                       = 'ANGLES'
TKFRAME -203110 UNITS = 'DEGREES'
TKFRAME -203110 ANGLES
                      = (0.0, 0.0, 0.0)
TKFRAME -203110 AXES
                       = (1, 2, 3)
```


The "FRAME_<name> = <id>" and "FRAME_<id>_NAME = <name>" keywords establish the association between the name and ID of the frame



```
FRAME_DAWN_SPACECRAFT = -203000
FRAME_-203000_NAME = 'DAWN_SPACECRAFT'
FRAME_-203000_CLASS = 3
FRAME_-203000_CLASS_ID = -203000
FRAME_-203000_CENTER = -203
CK_-203000_SCLK = -203
CK_-203000_SPK = -203
```

```
FRAME DAWN FC1
                       = -203110
FRAME -203110 NAME
                       = 'DAWN FC1'
FRAME -203110 CLASS
FRAME -203110 CLASS ID
                       = -203110
FRAME -203110 CENTER
                       = -203
TKFRAME -203110 RELATIVE = 'DAWN SPACECRAFT'
TKFRAME -203110 SPEC
                       = 'ANGLES'
TKFRAME -203110 UNITS = 'DEGREES'
TKFRAME -203110 ANGLES
                       = (0.0, 0.0, 0.0)
                       = (1, 2, 3)
TKFRAME -203110 AXES
```

- The FRAME...CLASS keyword specifies the method by which the frame is related to its base frame
- This keyword is set to:
 - 2 for PCK-based frames
 - 3 for CK-based frames
 - 4 for fixed-offset frames
 - 5 for dynamic frames



```
FRAME_DAWN_SPACECRAFT = -203000

FRAME_-203000_NAME = 'DAWN_SPACECRAFT'

FRAME_-203000_CLASS = 3

FRAME_-203000_CLASS_ID = -203000


FRAME_-203000_CENTER = -203

CK_-203000_SCLK = -203

CK_-203000_SPK = -203
```

```
FRAME DAWN FC1
                        = -203110
FRAME -203110 NAME
                        = 'DAWN FC1'
FRAME -203110 CLASS
FRAME -203110 CLASS ID
                        = -203110
FRAME -203110 CENTER
                        = -203
TKFRAME -203110 RELATIVE = 'DAWN SPACECRAFT'
TKFRAME -203110 SPEC
                        = 'ANGLES'
TKFRAME -203110 UNITS
                        = 'DEGREES'
TKFRAME -203110 ANGLES
                        = (0.0, 0.0, 0.0)
                        = (1, 2, 3)
TKFRAME -203110 AXES
```

- The FRAME...CLASS_ID is the number that connects a frame with the orientation data for it.
 - For body-fixed frames the CLASS_ID is the ID of the natural body. It is used as input to PCK routines called by the Frame subsystem to compute orientation of the frame.
 - » The Frame ID and CLASS_ID are <u>not</u> the same for the body-fixed frames defined in the Toolkit but they <u>can</u> be the same for frames defined in FK files.
 - For CK-based frames the CLASS_ID is the CK structure ID. It is used as input to CK routines called by the Frame subsystem to compute orientation of the frame.
 - » Usually the CLASS_ID of a CK-based frame is the same as the frame ID, but this is not required.
 - For fixed offset and dynamic frames the CLASS_ID is the ID that is used to retrieve the frame definition keywords.
 - » The CLASS_ID of a fixed offset or dynamic frame is the same as the frame ID.



Navigation and Ancillary Information Facility

```
FRAME_DAWN_SPACECRAFT = -203000

FRAME_-203000_NAME = 'DAWN_SPACECRAFT'

FRAME_-203000_CLASS = 3

FRAME_-203000_CLASS_ID = -203000


FRAME_-203000_CENTER = -203

CK_-203000_SCLK = -203

CK_-203000_SPK = -203
```

```
FRAME DAWN FC1
                       = -203110
FRAME -203110 NAME
                       = 'DAWN FC1'
FRAME -203110 CLASS
FRAME -203110 CLASS ID
                       = -203110
FRAME -203110 CENTER
                       = -203
TKFRAME -203110 RELATIVE = 'DAWN SPACECRAFT'
TKFRAME -203110 SPEC
                       = 'ANGLES'
TKFRAME -203110 UNITS
                       = 'DEGREES'
TKFRAME -203110 ANGLES
                       = (0.0, 0.0, 0.0)
TKFRAME -203110 AXES
                       = (1, 2, 3)
```

- The FRAME...CENTER specifies the ephemeris object at which the frame origin is located
 - It is used ONLY to compute the light-time corrected orientation of the frame



Navigation and Ancillary Information Facility

```
FRAME_DAWN_SPACECRAFT = -203000

FRAME_-203000_NAME = 'DAWN_SPACECRAFT'

FRAME_-203000_CLASS = 3

FRAME_-203000_CLASS_ID = -203000


FRAME_-203000_CENTER = -203

CK_-203000_SCLK = -203

CK_-203000_SPK = -203
```

```
FRAME DAWN FC1
                       = -203110
FRAME -203110 NAME
                       = 'DAWN FC1'
FRAME -203110 CLASS
FRAME -203110 CLASS ID
                       = -203110
FRAME -203110 CENTER
                       = -203
TKFRAME -203110 RELATIVE = 'DAWN SPACECRAFT'
TKFRAME -203110 SPEC
                       = 'ANGLES'
TKFRAME -203110 UNITS = 'DEGREES'
TKFRAME -203110 ANGLES
                       = (0.0, 0.0, 0.0)
TKFRAME -203110 AXES
                       = (1, 2, 3)
```

- Additional keywords are included depending on the frame class
 - For CK frames, CK...SCLK and CK...SPK keywords identify the spacecraft clock ID and physical object ID associated with the CK structure ID
 - For fixed-offset frames, TKFRAME_* keywords specify the base frame and the fixed orientation with respect to this frame
 - For dynamic frames, additional keywords depend on the dynamic frame family




CK-Based Frames "Must Know"

Navigation and Ancillary Information Facility


These are VERY IMPORTANT points you must understand!

- The frames routines (SPKEZR, SPKPOS, SXFORM, PXFORM) all read CK files using tolerance = 0
 - For discrete CKs the orientation of a CK-based frame will be computed only if the time provided to a Frames routine exactly matches one of the times stored in the CK file; otherwise an error will be signaled.
 - For continuous CKs the orientation of a CK-based frame will be computed only if the time provided to a Frames routine falls within one of the interpolation intervals defined by the CK file; otherwise an error will be signaled.
- Using SPKEZR or SXFORM requires CKs with angular rates
 - Since these routines return a state vector (6x1) or state transformation matrix (6x6), angular rates must be present in the CK in order to compute vectors and matrices; if rates are not present, an error will be signaled.
 - SPKPOS and PXFORM, which return a position vector (3x1) and a position transformation matrix (3x3) respectively, can be used instead because they require only orientation data to be present in the CK.
- Ephemeris time input to Frames routines is converted to SCLK to access CKs
 - SCLK and LSK kernels must be loaded to support this conversion.
 - SCLK ID is specified in one of the CK frame definition keywords; if not, it's assumed to be the Frame ID divided by a 1000.




Frame Tree Example: ASPERA Instrument on Mars Express

Navigation and Ancillary Information Facility



Blue text indicates frame class



FK Utility Programs

Navigation and Ancillary Information Facility

 The following FK and frames utility programs are included in the Toolkit:

FRMDIFF samples orientation of a frame or compares orientation of

two frames

CKBRIEF summarizes coverage for one or more CK files


BRIEF summarizes coverage for one or more binary PCK files

 These additional FK and frames utility programs are provided on the NAIF Web site (http://naif.jpl.nasa.gov/naif/ utilities.html)

PINPOINT creates SPK and topocentric frames FK files for fixed

locations (ground stations, etc)

BINGO converts FK files between UNIX and DOS text formats



Additional Information on FK

- For more information about FK and frames, look at the following documents
 - Frames Required Reading
 - Using Frames Tutorial
 - Dynamic Frames Tutorial
 - NAIF IDs Tutorial
 - headers for the routines mentioned in this tutorial
 - Most Useful SPICELIB Routines
 - FRMDIFF User's Guide
 - Porting_kernels tutorial
- Related documents
 - CK Required Reading
 - PCK Required Reading
 - SPK Required Reading
 - Rotations Required Reading